## LVV-T2290

December 14, 2021

## 1 Slew, Track and Image taking with ComCam

This notebook is used for the level 3 integration tests from test plan LVV-P81 (https://jira.lsstcorp.org/secure/Tests.jspa#/testPlan/LVV-P81) as part of test cylce LVV-C176 (https://jira.lsstcorp.org/secure/Tests.jspa#/testCycle/LVV-C176). The following tests are currently run as part of this notebook:

• LVV-T2290 (https://jira.lsstcorp.org/secure/Tests.jspa#/testCase/LVV-T2290)

Execution steps are separated by horizontal lines. Upon completion, save the notebook and its output as a pdf file to be attached to the test execution in JIRA.

Last executed by E. Dennihy 20210928

Run the setup.ipnyb notebook to bring all components up and in their enabled position. Check Chronograph.

Bring ComCom online and transition it to EnabledState. Check Chronograph.

[1]: %load ext autoreload

```
%autoreload 2

[2]: import rubin_jupyter_utils.lab.notebook as nb
```

```
/tmp/ipykernel_13626/1665379685.py:2: DeprecationWarning: Call to deprecated function (or staticmethod) get_node. (Please use lsst.rsp.get_node())
```

[2]: 'yagan06'

nb.utils.get\_node()

nb.utils.get\_node()

```
[3]: import os
import sys
import asyncio
import logging

import pandas as pd
import numpy as np
```

```
from matplotlib import pyplot as plt
     from lsst.ts import salobj
     from lsst.ts.observatory.control.maintel import MTCS, ComCam
     from lsst.ts.observatory.control import RotType
    <IPython.core.display.HTML object>
    <IPython.core.display.HTML object>
[4]: logging.basicConfig(format="%(name)s:%(message)s", level=logging.DEBUG)
[5]: log = logging.getLogger("setup")
     log.level = logging.DEBUG
[6]: domain = salobj.Domain()
[7]: mtcs = MTCS(domain=domain, log=log)
     mtcs.set_rem_loglevel(40)
    <IPython.core.display.HTML object>
    <IPython.core.display.HTML object>
[8]: await mtcs.start task
    <IPython.core.display.HTML object>
    <IPython.core.display.HTML object>
    <IPython.core.display.HTML object>
[8]: [None, None, None, None, None, None, None, None, None]
    <IPython.core.display.HTML object>
    <IPython.core.display.HTML object>
    <IPython.core.display.HTML object>
```

```
<IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
[25]: comcam = ComCam(domain=domain, log=log)
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
[26]: comcam.set_rem_loglevel(40)
[27]: await comcam.start_task
[27]: [None, None, None]
[28]: await comcam.enable()
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
       AttributeError
                                                 Traceback (most recent call last)
       /tmp/ipykernel_13626/218385458.py in <module>
       ---> 1 await comcam.enable()
       ~/auto-op-env-packages/ts_observatory_control/python/lsst/ts/observatory/control/
       →remote_group.py in enable(self, settings)
                       self.log.info("Enabling all components")
           893
           894
       --> 895
                       settings_all = await self.expand_settings(settings)
```

```
896
    897
               await self.set_state(salobj.State.ENABLED, settings=settings_al
~/auto-op-env-packages/ts_observatory_control/python/lsst/ts/observatory/control/
 →remote group.py in expand settings(self, settings)
    700
                           )
    701
--> 702
               incomplete settings = await self.inspect settings(
    703
                    components attr=[
    704
                       comp for comp in self.components_attr if comp not in_
 ~/auto-op-env-packages/ts_observatory_control/python/lsst/ts/observatory/control/
 →remote_group.py in inspect_settings(self, components_attr)
               for comp in settings:
    647
    648
                   try:
--> 649
                       sv = await getattr(self.rem, comp).evt_settingVersions.
 →aget(
    650
                           timeout=self.fast timeout
    651
                       )
AttributeError: 'Remote' object has no attribute 'evt_settingVersions'
```

Find four targets separated by  $5^{\circ}$  in azimuth and elevation in a square pattern around az =  $120^{\circ}$  and el =  $60^{\circ}$  and rotator angle at PhysicalSky and  $1.8^{\circ}$ .

At this position, the rotator stays within a couple of degrees of its initial position. This is because the CCW is not running (MTmount in simulation mode).

```
target_1 -> az = 117.5^{\circ}, el = 57.5^{\circ}
target_2 -> az = 122.5^{\circ}, el =57.5^{\circ}
target_3 -> az = 122.5^{\circ}, el=62.5^{\circ}
target_4 -> az = 117.5^{\circ}, el = 62.5^{\circ}
```

```
[13]: target_1 = await mtcs.find_target(az=117.5, el=57.5, mag_limit=8)
    target_2 = await mtcs.find_target(az=122.5, el=57.5, mag_limit=8)
    target_3 = await mtcs.find_target(az=122.5, el=62.5, mag_limit=8)
    target_4 = await mtcs.find_target(az=117.5, el=62.5, mag_limit=8)

print(f"Target 1: {target_1}"
    f"Target 2: {target_2}"
    f"Target 3: {target_3}"
    f"Target 4: {target_4}")
```

Target 1: HD 167952Target 2: HD 166944Target 3: V\* V1090 ScoTarget 4: HD 162309

## Slew to target 1:

```
[14]: await mtcs.slew_object(target_1, rot_type=RotType.PhysicalSky, rot=1.9)
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
```

```
<IPython.core.display.HTML object>
     Once on target_1 and tracking, take an image with ComCam
[15]: exp1 = await comcam.take_object(15)
      print(f"Target 1 exposure: {exp1}")
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
     Target 1 exposure: [2021121400001]
     Slew to target 2:
[16]: await mtcs.slew_object(target_2, rot_type=RotType.PhysicalSky, rot=1.9)
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
```

<IPython.core.display.HTML object>

<IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object> <IPython.core.display.HTML object>

```
<IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
     Once on target 2 and tracking, take an image with ComCam
[17]: exp2 = await comcam.take object(15)
      print(f"Target 1 exposure: {exp2}")
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
     Target 1 exposure: [2021121400002]
     Slew to target_3
[18]: await mtcs.slew_object(target_3, rot_type=RotType.PhysicalSky, rot=1.9)
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
```

<IPython.core.display.HTML object>

```
<IPython.core.display.HTML object>
```

Once on target 3 and tracking, take an image with ComCam

```
[19]: exp3 = await comcam.take_object(15)
print(f"Target 1 exposure: {exp3}")

<IPython.core.display.HTML object>
```

<IPython.core.display.HTML object>

```
<IPython.core.display.HTML object>
Target 1 exposure: [2021121400003]
```

Slew to target 4

```
[20]: await mtcs.slew_object(target_4, rot_type=RotType.PhysicalSky, rot=1.9)
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
```

```
<IPython.core.display.HTML object>
```

Once on target\_4 and tracking, take an image with ComCam

Stop tracking to prevent hitting the Rotator soft limit.

Use ComCam recent images CCS to ensure that the images were taken (http://ccs.lsst.org/RecentImages/comcam.html).

Query the butler to verify that the images are there and check the metadata. This step must be verified using a separate noteboook.

Wrap Up and Shut Down

This cell is not currently included as part of the test execution, but included here as needed to shutdown the systems

```
[]: await mtcs.set_state(salobj.State.STANDBY, components=["mtaos"])
[]: await mtcs.lower_m1m3()
[]: await mtcs.set_state(salobj.State.STANDBY, components=["mtm1m3"])
[]: await mtcs.set_state(salobj.State.STANDBY, components=["mtm2"])
[]: await mtcs.set_state(salobj.State.STANDBY, components=["mthexapod_1"])
[]: await mtcs.set_state(salobj.State.STANDBY, components=["mthexapod_2"])
[]: await mtcs.standby()
```